

NETGEAR Router - Mozilla

File Edit View Go Bookmarks Tools Window Help

http://192.168.0.1/rpSys.html

NETGEAR



[WIZARD SETUP](#)

[ADVANCED](#)

[MAINTENANCE](#)

[LOGOUT](#)

Welcome to the NETGEAR Router Configuration Utility !

You can click on the Wizard Setup or other topics on the Main Menu located in the left frame.

The Wizard Setup will lead you through the NETGEAR router configuration process step by step. To use the Wizard Setup you should have your Internet Service Provider (ISP) Information handy, along with your NETGEAR Manual (Located on the CD) to use as a reference.

Advanced users can click on the items on the Main Menu panel for more advanced configuration settings.


Document: Done (0.16 secs)

NETGEAR Router - Mozilla

File Edit View Go Bookmarks Tools Window Help

http://192.168.0.1/rpZard.html

NETGEAR HELP ?



MAIN MENU

LOGOUT

WIZARD SETUP

General Setup :
This information is optional, but may be helpful in accessing services of your Internet Service Provider, such as mail and news servers and customer support web pages.

Enter the System Name (may be called Host Name or Account Name) that is assigned to you by your Internet Service Provider.

System Name :

The ISP's Domain Name is often sent automatically by the ISP to the router. If you are having difficulty accessing ISP services, you may need to enter the Domain Name manually in the box below.

For example, if the full address of your ISP's mail server is :
mail.xxxx.yyyy.myisp.com, then the Domain Name is
xxxx.yyyy.myisp.com

Domain Name :

Status: Ready


Document: Done (0.475 secs)

NETGEAR Router - Mozilla

File Edit View Go Bookmarks Tools Window Help

http://192.168.0.1/rpZard.html

NETGEAR HELP ?



[MAIN MENU](#)

[LOGOUT](#)

WIZARD SETUP

Wireless LAN Setup

The ESSID is used to distinguish your private wireless network from other wireless networks that may be near you.

All Wireless PC Cards and Access Points connecting to this router will need to use the same ESSID and Channel as listed below.

ESSID

Channel

Note:
For Network Security, it is recommended that you change the default ESSID name of your wireless network. The default channel does not need to be changed unless you are experiencing interference from another access point.

Status: Ready


Document: Done (0.087 secs)

NETGEAR Router - Mozilla

File Edit View Go Bookmarks Tools Window Help

http://192.168.0.1/rpZard.html

NETGEAR HELP ?



MAIN MENU

WIZARD SETUP

ISP Parameters for Internet Access

Encapsulation

User Name

Password

Idle Timeout Seconds.

PPTP Configuration

My IP Address

Server IP Address

Connection ID/Name

Status: Ready


Document: Done (0.09 secs)

NETGEAR Router - Mozilla

File Edit View Go Bookmarks Tools Window Help

http://192.168.0.1/rpZard.html

NETGEAR HELP ?



WIZARD SETUP

[MAIN MENU](#)

[LOGOUT](#)

WAN IP Address Assignment

Get automatically from ISP (Default)

Use fixed IP address

IP Address	0.0.0.0
IP Subnet Mask	255.0.0.0
Gateway IP Address	0.0.0.0

DNS Server Address Assignment

Get automatically from ISP (Default)

DNS IP Fixed Address

Primary DNS Server	0.0.0.0
Secondary DNS Server	0.0.0.0

WAN MAC address

Factory default

Spoof this PC's MAC address --- IP Address 192.168.0.2

Back Next

Status: Ready


Document: Done (0.093 secs)

NETGEAR Router - Mozilla

File Edit View Go Bookmarks Tools Window Help

http://192.168.0.1/rpZard.html

NETGEAR HELP ?



MAIN MENU

WIZARD SETUP

Please Click the Finish Button to Complete the Wizard Setup.

NOTE:

If you are currently using a Wireless PC card to access this router AND you made changes to the ESSID, then you will need to make the same changes to your Wireless PC card AFTER you click the Finish Button.

Once the changes have been made to the Wireless PC card, you will be able to connect back to the router and continue the configuration process.

Back Finish

Status: Ready


Document: Done (0.091 secs)

NETGEAR Router - Mozilla

File Edit View Go Bookmarks Tools Window Help

http://192.168.0.1/rpZard.html

NETGEAR HELP ?



WIZARD SETUP

Congratulations ! Your NETGEAR Router Internet Access Configuration is done.

You should be able to access the Internet now. You can try it by going to the NETGEAR home page at <http://www.netgear.com>

You can also click on Main Menu for system status, or click on Logout to exit this web configurator

MAIN MENU

LOGOUT

Status: Ready


Document: Done (0.094 secs)

NETGEAR Router - Mozilla

File Edit View Go Bookmarks Tools Window Help

http://192.168.0.1/rpSys2.html

NETGEAR HELP ?



WIRELESS LAN SETUP

Setup **Access Filter**

Wireless LAN Setup

ESSID

Channel

RTS Threshold Default (0 ~ 2432)

Fragment Threshold Default (256 ~ 2432)

WEP Encryption

WEP Key Generator

Passphrase

Web Manual Entry

64-bit WEP: Enter 10 characters ("0-9", "A-F") for each Key(1-4).
 128-bit WEP: Enter 26 characters ("0-9", "A-F") for each Key(1-4).

Key 1

Key 2

Key 3

Key 4

Status: Ready

Document: Done (0.123 secs)